


Trouble Shooting

The Water Widget has been specifically designed to save energy and water in particular showering applications. As such the Water Widget can self test and indicate by water squirting out of the air vent if your shower is not suitable for the water widget.

Problem	Solution
Water is continuously squirting out of the air intake.	Water Widget incorrectly assembled. Take apart & re assemble following instructions to ensure that inductor is the correct way round. If problem persists application is not suitable for fitting the water widget.
	Your shower head may already have water saving device installed and the application is not suitable for fitting the water widget.
	Water pressure is too low and the application is not suitable for fitting the water widget.
	Electric showers have very low flows already and may not be suitable for fitting the water widget.
When shower is switched off or changes between functions water leaks from the air inlet.	This is normal.
Small amounts of water or water intermittently leaking from air intake.	This is normal no action required.
Water leaking from between shower head and water widget.	Water widget is not seated correctly on to washer. Remove showerhead and make sure washer is seated correctly.
Sucking noise from air intake.	This is normal.

Descaling your showerhead will improve the performance of the Water Widget

If water squirts out...



IMPORTANT: if water squirts out the air inlet hole then you have probably got the inner inductor the wrong way round. Please take apart the water widget and insert the inner inductor the correct way round - see Fitting Instructions.

Where the Water Widget is not suitable for your particular shower, please return to the Free Post address detailed below.

Freepost: RSGU-GCYX-GHXU

Berkshire SL6 9EH

Watch our new instructions video at
www.waterwidget.co.uk

Patent Number 0906171



Save the planet from the comfort of your own shower

Fitting and User instructions

The Water Widget can be easily fitted to new and existing showers next to the shower head. It can reduce the amount of water used by a shower by up to 70% which can result in a saving of up to £100 off the annual bill for a typical 3 bedroom house.


Fitting a Water Widget saves energy and water and reduces Carbon footprint.

Please leave these instructions with the shower instructions.

The Water Widget is not suitable for low flow showers and not recommended for electric showers

5 Simple steps to fit to a shower and hose

Typical application shown



Fitting Instructions

1. Attach/Insert new washer to showerhead
2. Screw Water Widget Housing to showerhead
3. Insert inductor into housing (it will only go one way)
4. Attach/Insert new washer
5. Screw showerhead & attached Water Widget complete to shower hose or arm

Before fitting the Water Widget check and remove from showerhead & pipe work **ANY** old washers or restrictors, then descale the showerhead.

CONGRATULATIONS!

Watch our new instructions video at
www.waterwidget.co.uk

5 simple steps to fit to fixed arm shower head

Typical application shown

